



Instructions for Setting Voltage Selector Switch - Model 3460 Nests

When installing a new Model 3460 Nest or connecting to a new power source, it will be necessary to match the Voltage Selector Switch to the voltage of the power source used for the installation. The Voltage Selector Switch is located in the center of the Model 3460 Nest's rear panel. To set the Voltage Selector Switch to the appropriate voltage, please follow the steps listed below.


Step 1 - Remove the warning label which is placed over the Voltage Selector Switch at Telenetics' production facility. (Figure 1)



Step 2 - Open Voltage Selector Switch cover as shown in Figures 2 and 3.



Step 3 - Rotate Voltage Selector Switch to the correct voltage for your installation as shown in Figure 3.



Step 4 - Close cover. (Figure 4)

